



## MOUNTING

Remove the two cover screws. Select a location on an outside wall away from any warm air outlets such as windows or extract ducts. Avoid fixing to chimney stacks or other artificially warm surfaces.

Unzoned Buildings – locate on an outside wall exposed to prevailing winds and in continuous shade, preferably near the top of the building unsheltered by surrounding buildings.

Zoned buildings – for aspect zoning, locate the sensor so that it faces in the same general direction as the window area of the zone being controlled. For horizontal zoning locate as near the top of the zone as possible.

Access for wiring is via M20 conduit connections and the terminals are accessed via the removable cover (two screws). The terminals are not polarised. See wiring diagram.

## WIRING

